

MEGAPHONE (07-0022)

MOUNTING THE PIVOT BRACKETS


TOOLS REQUIRED: SMALL PHILLIPS SCREWDRIVER OR P2 BIT WITH ELECTRIC SCREWDRIVER

PARTS INCLUDED:

- 1- MEGAPHONE WITH RUBBERIZED MOUTH PIECE ATTACHED
- 2- PIVOT BRACKETS
- 2- L-SHAPED MOUNTING BRACKETS
- 7- M4 X 30mm PHILLIPS COUNTERSUNK HEAD SCREWS

1: PLACE THE MEGAPHONE BETWEEN THE TWO PIVOT BRACKETS.


2: ATTACH THE TWO PIVOT BRACKETS TOGETHER WITH AN M4 x 30mm PHILLIPS COUNTERSUNK HEAD SCREW .



FOR RESIDENTIAL USE ONLY
FOR CHILDREN AGES 3-11

MEGAPHONE (07-0022) MOUNTING TO 4 X 4 BOARD

- 1: CENTER THE MEGAPHONE ON TOP OF THE 4 X 4 BOARD.
- 2: PLACE THE PIVOT BRACKETS ON TOP OF 4 X 4 BOARD AND ATTACH WITH THE M4 x 30mm PHILLIPS COUNTERSUNK HEAD SCREWS PROVIDED.
- 3: THE LEFTOVER "L" SHAPED MOUNTING BRACKETS MAY BE DISCARDED SINCE THEY ARE USED TO MOUNT THE MEGAPHONE TO A 2 X 4 BOARD.




FOR RESIDENTIAL USE ONLY
FOR CHILDREN AGES 3-11

MEGAPHONE (07-0022) MOUNTING TO 2 X 4 BOARD

1: PLACE ONE OF THE "L" SHAPED BRACKET AGAINST THE 2 X 4 BOARD SO THAT THE BRACKET SECTION WITH THE CUTOUT FACES UP. FASTEN THE "L" SHAPED BRACKET TO THE 2 X 4 BOARD WITH THE M4 x 30mm PHILLIPS COUNTERSUNK HEAD SCREWS PROVIDED.

2: PLACE THE MEGAPHONE PIVOT BRACKET INSIDE THE CUTOUT SECTION OF THE MEGAPHONE BRACKET ON THE 2 X 4 BOARD.

3: PLACE ANOTHER "L" SHAPED BRACKET DIRECTLY ACROSS FROM THE OTHER BRACKET . FASTEN THE "L" SHAPED BRACKET TO THE 2 X 4 BOARD WITH THE M4 x 30mm PHILLIPS COUNTERSUNK HEAD SCREWS PROVIDED.



FOR RESIDENTIAL USE ONLY
FOR CHILDREN AGES 3-11